# Version 1.5.1 (15/12/2023)

### New features:

Improved daemon starting and stopping. The daemon status will less likely to report an error while starting or stopping.

Added support file generation button on the general page of the installation node. When a problem occurs, the user can click this button and all necessary files will be collected.

Improved request and load license operation for in URSim. The generated license\_request file will be created in the directory /home/ur/ursim-current/programs. For loading a license in URSim, the license file can also be placed in this directory prior to pressing the "Load license" button.

### Bug fixes:

Solved bug where loading a program with a different installation could result in the daemon to be registered to be not running, even though that installation was saved with the daemon registered to be running.

Solved bug where loading another program could result in an error being thrown with in the error file the message mentioning "No new variable for iSee Ui".

## Version 1.5.0 (20/10/2023)

#### New features:

Made URCap compatible with newer .isui file version (version 1.5) corresponding with Builder version 1.6.0.

### Bug fixes:

Solved bug where a disabled TextField or PasswordField still allowed the operator to interact with it and change the value. Now the item will not respond when it is disabled.

Solved bug where a reset of the iSee Ui (using the iSee Ui reset node) did not reset the enabled property of an item.